Menübaum

Connect AC input/DC output

↓

Turn on AC input MCB



↓

On the right 2 pictures will be displayed on the screen in turn.

↓

Touch anywhere on display screen.

↓

The Main interface (3 different charging Mode):
Automatic charging
Charging by power
Charging by time



↓

Click Automatic charging
Noted: if plug not connected, here it will mention in red and alarm.



↓ ①

"Charging" will be displayed on the touch-screen display along with the remaining battery capacity and charge time.

↓

Start charging.

Charging completed.



It can be cannelled charging anytime. Click “Cancal”.

②

Charging by power
We can set to charge@ KW/H.

Type the No. (Max 6 No., include the point, such as 999999.99)
For example: 10. Press”OK”

Starting charging.

③

Charging by time
We can set the charging time(Minutes, Max 6 No. That is Max 999999).

Charging by time
We can set the charging

2.4 Background setting

1.Click the upper right corner of the screen, 5 continues times. Then you will see below screen ①.

2. Password is 123 and confirm by

3. Then picture ② will be displayed on the screen.

4. You can set these 4 parameters.



①

②